




Description

How to check Hydraulic brake level active or disactive is a big issues on ebike ,Now ,this trouble was complete solved after BK-2R launched.
This sensor combined with 2 parts one is sensor body and others is a small magnet , size is very small so only need to stick both of them on the brake level, then , it can check the brake active and disactive and a switch signal will be output.

Specification

- Model : BK-2R
- Signal : Active : switch off
InActive: switch on
- Housing material : Intensive ABS
- Sensor Size : 26x11.5x6mm
- Magnet Size : Φ10x3mm
- Net Weight : 4g



Install Guide



Pack List

- Sensor x1
- Magnet x1
- 3M Gummed tape x2

Interface

Connector : SM2 or Other

How to order

- Items below must be declared clearly before order
- Model & Quantity
 - Connector type
 - Cable length
 - Other special requirements